



INSTALACJA:

- 1) Przymocować rurę (1) do baterii (2) kluczem do nakrętek
- 2) Należy przymocować wylewkę (9) do metalowej rury (1) przykręcając kluczem do nakrętek
- 3) Zainstalować uchwyt mocujący spryskiwacz (15) do metalowej rury (1) w celu przymocowania przyszcina śrubami imbusowymi (16)
- 4) Przymocować tuleję mocowania (4) do trzpienia (3) (rysunek 1)
- 5) Trzpień mocujący baterię do ściany (3) umieścić w metalowej rurze (1) w celu umocowania go w ścianie za pomocą śrub imbusowych (6)
- 6) Zainstalować tuleję mocowania sprężyny (7) na rurę (1) łącząc je ze sobą w odległości około 220mm (rysunek 2)
- 7) Umocować trzpień mocujący baterię do ściany (3) do rury (1) ...
- 8) Umocować uszczelkę węża spryskiwacza (10) i wąż spryskiwacza (11) do rury (1)
- 9) Nałożyć sprężynę (12) (rysunek 3) w celu umieszczenia jej w tulei (7) (rysunek 4)
- 10) Umocować trzpień (3) oraz spryskiwacz (14) na końcówkach węża (11)
- 11) Przymocować uchwyt (15) do rury (1) za pomocą śrub imbusowych (16) w odległości, która pozwala na założenie spryskiwacza
- 12) Należy się upewnić, że wszystkie elementy zostały tak zamontowane, by uniknąć ewentualnych wycieków

PRE-RINSE UNIT INSTALLATION:

- 1) fix the tube (1) into the body (2) and fix it with a spanner
- 2) fix the swivel nozzle (9) into the metal tube (1) and tighten it with a spanner
- 3) install the spray gun bracket (15) into the metal tube (1) in order to fix the shower and pre-screw the knobs (16)
- 4) fix the rosone (4) into the bar (3) and fix it (5) (pic. 1)
- 5) put the bar (3) into the tube (1) in order to fix it on the wall and pre-screw the knobs (6)
- 6) install the tongs place (7) into the tube (1) and fix it (8) at a distance of 220mm ca. (pic. 2)
- 7) fix the bar for the wall fixing (3) into the tube (1) throw the narrowing of the knobs (6) at the needed distance (pic. 2)
- 8) fix the gasket (10) and the flexible (11) into the tube (1)
- 9) insert the spring (12) (pic. 3) in order to put it in its place (7) (pic. 4)
- 10) fix the gasket (3) and the shower (14) to the other end of the flexible hose (11)
- 11) fix the bracket (15) into the tube (1) throw the narrowing of the knobs (16) at a distance that allow you to fix the shower
- 12) make sure that all components have been fixed in order to avoid leaks

970515

