



stalgast

ekspert gastronomiczny

USER MANUAL

Electric chafing dish with soup kettles

MODEL: 433241



CONTENTS

1. SAFETY INSTRUCTIONS	3
2. STRUCTURE OF THE DEVICE	3
2.1. Description of the device	4
3. TECHNICAL SPECIFICATION	4
4. ASSEMBLY	4
4.1. Connecting to the source of electricity.....	4
5. OPERATING THE DEVICE	4
6. CLEANING AND MAINTENANCE	4
7. TROUBLESHOOTING	5
8. END-OF-SERVICE LIFE RECYCLING	5
9. WARRANTY	5

Thank you for your purchase of a Stalgast product. Before use please familiarize yourself in detail with the following instruction manual.

Copying of the following manual without the consent of the manufacturer is prohibited.

Images and drawings are of illustrative character and may differ from the purchased product.

Attention: This manual should be kept in a safe place accessible for personnel. The manufacturer reserves the right to change the technical characteristics of the product without any notice.

I. SAFETY INSTRUCTIONS

- Incorrect maintenance and/or use may cause serious harm to people and damage the device.
- The device can only be used for the purpose for which it has been designed.
- The manufacturer does not take any responsibility for damages caused by improper maintenance or use of the device.
- When in use, secure the device and its electrical plug from any contact with water or other fluids. In case the device is accidentally dropped into water the electrical plug should be immediately removed from the socket and the device should be inspected by a trained professional.

Failure to obey these instructions may cause life threatening danger.

- Never open the casing of the device on your own.
- Do not stick any objects into the casing of the device.
- Do not touch the electrical plug with wet hands.
- Check the condition of the electrical plug and cord regularly. In case any damage to the plug or cord is discovered order repair by a specialized service provider.
- In case the device is dropped or damaged otherwise, before further use always order a check-up and repair by a specialized service provider.
- Do not make any attempts to repair the device on your own – this may cause life threatening danger.
- Protect the electrical cord from contact with sharp or hot objects and keep it away from open fire. When you disconnect the device from the electrical socket always hold the plug and never pull the electrical cord.
- Secure the electrical cord (or the extension cord), so that it is not unplugged by mistake and so that no one can stumble over it.
- Monitor functioning of the device while in use.
- Use of the device by people underage, physically or mentally incapable, with motion disorders as well as people without proper experience and knowledge regarding the use of this device should not be allowed. All of the above should only use the device under supervision of a person responsible for their health and safety.
- When not used or during maintenance you should always unplug the device from the source of electricity by removing the electrical plug from the socket.
- ATTENTION: when the electrical plug is plugged into the socket the device is constantly live.
- Switch the device off before removing the plug from the socket.
- Never pull the device by the electrical cord.


Do not use any additional elements other than those supplied with the device. Never set the device in the proximity of heat sources (e.g. stoves or ovens).

2. STRUCTURE OF THE DEVICE

The electric chafing dish with two soup kettles (4l). The purpose of this device is to maintain the temperature of soup.

1. Temperature control knob – when water inside the device reaches proper temperature thermostat will disengage heating elements. When temperature falls more than 10 C below the set temperature heating elements will automatically turn on. When temperature control knob is turned to 85 C +/- 10 C steam may be visible around kettles. If the required temperature is lower turn the control knob down. Temperature is maintained with 10 C tolerance.
2. Indicator lights – the device is equipped with 2 indicator lights. Then it is connected to a source of electricity the indicator on the power switch is on. Activity of heating elements is indicated by an indicator located next to the temperature control knob.
3. Water level – the tank should be filled with water up to the level mark on the inside of the device. Do not overfill the tank. If the kettles float it means the tank has been overfilled. In case cold water is used to fill the tank the device should be turned on about 30 minutes before use. Using hot water shortens the time necessary to prepare this device to work.

2.1. Description of the device



3. TECHNICAL SPECIFICATION

Power input	230V@50Hz
Total generated power	2 kW
Dimensions	620x480x310mm
Capacity	2x 4l

4. ASSEMBLY

4.1. Connecting to the source of electricity

The device should be plugged into a 230V socket . The socket must be grounded.

5. OPERATING THE DEVICE

- Fill the tank with the correct amount of water. Blank kettles should not float on the water surface..
- Do not initiate the device when the tank is empty.
- Use the temperature control knob to set the correct temperature. (range is 0 to 85 °C)

Attention: remember to maintain a proper amount of water in the tank! Check the water level regularly, also when the device is in use.

6. CLEANING AND MAINTENANCE

- Always unplug the device before cleaning it.
- In case of heavy use remember to clean limescale sediment from the bottom of water tank.
- Never submerge the device into water or any other cleaning detergent.
- Clean the device with a damp cloth.
- Do not use abrasive or corrosive cleaning detergents to clean the device.
- Make sure none of the electrical elements of the device ever come in contact with water.

7. TROUBLESHOOTING

FAULT	POSSIBLE CAUSE	PROPOSED SOLUTION
The device does not work	No power in the socket	Check the fuse
	The socket is plugged in incorrectly	Check the plug
The device does not heat up to the desired temperature	Heating element damaged	Contact the seller
	Control unit damaged	Contact the seller
	Heating element fuse damaged	Contact the seller

8. END-OF-SERVICE LIFE RECYCLING

After the device reached its end-of-service life or when buying new equipment at Stalgast you can return the old device. Send it to us and a specialized company will recycle it in accordance with the ESOL for Electrical and Electronic Equipment Act (Legal Journal 2005 no. 180 point 1495).

9. WARRANTY

NOTE: Use water with a hardness of up to 6 ° dH. When water hardness exceeding 60 dH is recommended to install the device softener, which will extend the life and reliability of the device.

The seller provides warranty for the product.

Any damage resulting from settlement of calcium on the device is not covered by the warranty.

Such elements as light bulbs, rubber elements, heating elements damaged by limescale, screws and elements which naturally wear down such as heaters, gaskets, and any other elements damaged mechanically are not covered by the warranty.